

CameraRC Deluxe Edition 1.2.10 - Release Notes

CameraRC Deluxe Edition provides tethering support for the below listed Nikon cameras.

Nikon Cameras Supported

- D40^{1,2}
- D40X^{1,2}
- D60^{1,2}
- D80^{1,2}
- D90¹
- D200^{1,2}
- D300
- D300S
- D3
- D3X
- D3S
- D4
- D4S
- D5000¹
- D5100
- D5200
- D5300
- D5500
- D600
- D610
- D700
- D750
- D7000
- D7100
- D7200
- D800
- D800E
- D810
- D810A
- Df

¹ When installed on Windows 7 or later the Compatibility Mode must be set to Windows Vista Service Pack 2.

² These models are not supported on Mac El Capitan (OSX 10.11) and newer releases.

Enhancements

- Improvements in capture/download speed
- Improvements in Live View frame rate.
- Added Live View Frame Rate indicator to Live View Tab of Composition Aids.
- Enter key can be used trigger the shutter release on Live View Window, Camera Control Panel, Image Capture Viewer, and Thumbnail Viewer.
- Added Hide Movie Controls option to the general tab that hides all movie controls when they are not desired.
- Added Bright buttons option to the general tab that provides bright colored buttons for the

- Autofocus (AF), Live View (LV), Movie, and Shutter Release.
- Autofocus (AF) button is now hidden when in Manual Focus mode.
 - When Auto Image Rotation is disabled it is now possible to manually rotate the live view image.
 - Improved camera connection logic on Mac so that in most cases the camera can be connected after the program has started.

Bugs Fixed

- Mac Only - Corrected issue with Camera Control Panel (CCP) popping in front of active window when mouse is moved over area of CCP even if hidden. Behavior remains the same when in Live View.
- Bracket mode was sometimes incorrectly set both at camera and in program.

Known Issues

Program Limitations

- On Mac the program must be restarted when a camera is disconnected or turned off while the program is running.
- Only one camera can be connected and in use by the program on a single computer.
- Hot switching between camera models (i.e, Changing cameras while the program is running) is not allowed.
- Program cannot be installed onto a network share - can only be installed on a local disk drive.
- Images captured that are not focused in contrast mode live view (i.e., focus indicator not green) will incorrectly display the last phase detect focus point instead of displaying no focus point. The focus points are also incorrectly shown in Nikon Software as they are incorrectly stored in the image by the camera. The degree of this error varies depending on camera model.
- If there are a large number of images (100's) on the memory card installed in the camera it can take several minutes for the program to initialize.

System Requirements

- Windows Vista or later
- Mac OSX 10.8 - 10.10
- 2 Gbyte of RAM
- 50 Mbyte free disk space
- Recommended screen resolution 1024 X 768 - lower resolutions supported with scaling.